

# Transfert fichiers entre ordinateur et khepera

Utiliser la commande suivant :

De khepera au local

```
scp root@192.168.32.2:/repertoire/local/
```

```
scp /repertoire/local root@192.168.32.2:~/repertoire/khepera
```

```
xu@ubuntu:~$ scp root@192.168.32.2:~/lengagne/motor_initialize /home/xu/
root@192.168.32.2's password:
motor_initialize          100%  37KB 315.4KB/s   00:00
xu@ubuntu:~$ scp /home/xu/code/Programs/motor_initialize/motor_initialize root@1
92.168.32.2:~/P5A_XU_FRAU
root@192.168.32.2's password:
motor_initialize          100%  37KB 193.5KB/s   00:00
xu@ubuntu:~$ scp /home/xu/code/Programs/motor_stop/motor_stop root@192.168.32.2:
~/P5A_XU_FRAU
root@192.168.32.2's password:
motor_stop                100%  37KB 210.0KB/s   00:00
xu@ubuntu:~$ scp /home/xu/code/Programs/motion_arrowkeys/motion_arrowkeys root@1
92.168.32.2:~/P5A_XU_FRAU
root@192.168.32.2's password:
motion_arrowkeys          100%  42KB 65.2KB/s    00:00
```

exemple